

## KEY TO CHILDPROOFING YOUR HOME 12 SAFETY DEVICES TO PROTECT YOUR CHILDREN



1. **Safety Latches and Locks**- prevent poisonings, burns, and injuries
2. **Safety Gates**- prevents falls and keeps children out of dangerous areas
3. **Door Knob Covers and Door Locks**- keeps children away from hazards
4. **Anti-Scald Device**- helps prevent burns. Set hot water heater at 120 degrees.
5. **Smoke Detectors**-essential safety device for fire death and injury. Place on every level of the home and near bedrooms.
6. **Window Guards and Safety Netting**- prevents serious falls
7. **Corner and Edge Bumpers**- prevents scrapes and injuries from falls
8. **Outlet Covers and Outlet Plates**-prevent electrocution and shock
9. **Carbon Monoxide Detector**-prevents illness and death from CO poisoning
10. **Window Blind Cords, Safety Tassels, or Inner Cord Stops**- prevents strangulation
11. **Door Stops and Door Holders**-prevents injuries to fingers and hands
12. **Cordless Phone**-helps you watch a child continuously and provides access to quick response in case of an emergency

You can get window blind cord safety information and free tassels by calling 1-800-506-4636 or visiting [www.windowcoverings.org](http://www.windowcoverings.org)

Safety gates should display a certification seal from Juvenile Products Manufacturers Associations (JPMA).

Consumers can obtain the Childproofing Your Home publication and additional publication information from the [Publications section](#) of CPSC's web site or by sending your publication request to [info@cpsc.gov](mailto:info@cpsc.gov).