



**CONSTRUCTION NOTES:**

1. POSTS ARE SET 8'0" ON CENTER. POSTS ARE SET 24" DEEP IN SOIL W/ 48" REMAINING ABOVE. SET POSTS IN CONCRETE. USE CARPENTER'S LEVEL TO SET POST VERTICALLY.
2. STRINGERS A+C SHOULD BEGIN AND END ON THE SAME POSTS WHEN POSSIBLE. STRINGERS B SHOULD BEGIN AND END ON ALTERNATE POSTS FROM A+C WHEN POSSIBLE
3. THE 6" SIDE OF THE 4x6 POST SHOULD FACE FORWARD TO RECEIVE STRINGER BOARDS.

**MATERIALS LIST:**

1. LUMBER SCHEDULE FOR 1000 LINEAL FEET OF FENCE.

QUANTITY			BOARD FEET
125	POSTS	4"x6" x 6' (ORDER 63 12' LENGTHS; THEN CUT IN HALF)	1512
124	STRINGERS	2"x4" x 8'	655
124	STRINGERS	1"x6" x 16'	992
248	STRINGERS	1"x6" x 10'	1240
TOTAL BOARD FEET / 1000'			4389

2. USE 16d GALVANIZED NAILS OR COATED NAILS



FENCE SERIES	PL. NO. 8018
POST & RAIL FENCE	
DESIGN BY J. PERRY	SHEET 1
DRAWN BY D. SHURLEY	OF 1
DATE 5/1980	

